



**MARINE  
CARE**

# CARECLEAN QUICKSPLIT

**Solvent based quick separating oil and grease remover suitable for use in conjunction with oily water separators**

- Biodegradable
- Quick Separating
- Multipurpose
- High flashpoint
- Approved by:  
> Marinfloc

## DESCRIPTION

Careclean QuickSplit is a special degreasing agent for the removal of oil and grease from machines and motor parts, transmissions, ball bearings, gear wheels, metal parts, floorplates and bulkheads in the engine room. The cleaning emulsion with water and oil breaks up within a very short period.

## ADVANTAGE

- inherently biodegradable
- Good, quick cleaning properties
- odorless
- suitable for the removal of most mineral oils, fats, greases and preserving agents
- safe to use on all common metals, painted surfaces, epoxy and zinc-silicate coatings
- has the approval of major manufacturers for use in their oily water separators

## APPLICATIONS

Careclean QuickSplit is used to clean machinery, floor plates and bulkheads in engine rooms.

## DIRECTIONS FOR USE

### *General maintenance*

For cleaning in engine rooms etc., Careclean QuickSplit is used undiluted. Dampen the surface to be cleaned and let the product act for 5 - 60 minutes. Brush the surfaces occasionally and finally rinse them thoroughly with water at 50 - 60 °C. For heavier contamination we recommend Careclean Degreaser HD Split.



**MARINE CARE BV**  
Oude Maasweg 35  
Port Number 4005  
3197 KJ Botlek - Rotterdam  
The Netherlands  
T. +31 (0)10 2950342  
F. +31 (0)10 2950345  
E. [supply@marinecare.nl](mailto:supply@marinecare.nl)

### *Bilge Tanks*

To be used as a spot cleaner to decrease the amount of slops. Spray the contaminated surfaces until they are thoroughly dampened with undiluted Careclean QuickSplit. Let the product act for 5-60 minutes, then rinse thoroughly with water at 50 - 60 °C.

### *Immersion baths*

Careclean QuickSplit is applied undiluted at ambient temperature or up to a maximum of 55 °C in a heated bath. Soak components for several hours, remove from the bath and rinse thoroughly with a waterjet.

### *Note*

The use of emulsifying products will affect the separating properties of Careclean QuickSplit.

### **DOSAGE**

All types of cleaning                      undiluted

### **PROPERTIES**

Article number	14103
pH	Not applicable
Density	0,76 g/cm <sup>3</sup>
Flashpoint	> 62 °C
Physical state	Liquid

### **APPROVALS**

Marinfloc Approved OWS Compatible

For detailed information on safety and health, please refer to the Material Safety Data Sheet MSDS and/or product label.



# MARINE CARE

CARECLEAN QUICK-  
SPLIT

- Biodegradable
- Quick Separating
- Multipurpose
- High flashpoint
- Approved by:  
> Marinfloc



**MARINE CARE BV**  
Oude Maasweg 35  
Port Number 4005  
3197 KJ Botlek - Rotterdam  
The Netherlands  
T. +31 (0)10 2950342  
F. +31 (0)10 2950345  
E. supply@marinecare.nl