



**MARINE
CARE**

AM SCALE REMOVER LIQUID

- High efficiency
- Prevents scale in vacuum systems
- Non corrosive
- 100% bio degradable

Highly effective preventing scales in vacuum toilet systems

DESCRIPTION

AM Scale Remover Liquid is a blend of non corrosive organic acid, detergents and surfactants specially developed for the prevention of scales in Vacuum toilet systems. AM Scale Remover Liquid is highly effective on urea stones and similar scales present in lines and headers of vacuum toilet systems.

ADVANTAGE

- Economical to use
- Non corrosive
- Prevents urea scales from Vacuum systems

APPLICATIONS

AM Scale Remover Liquid is mainly used for preventing of Vacuum toilet systems.

SCALE REMOVAL (CLEANING)

For periodic cleaning purposes for the removal of scales, AM Scale Remover Powder can be used.



MARINE CARE BV
Oude Maasweg 35
Port number 4005
3197 KJ Rotterdam Botlek
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. supply@marinecare.nl
W. www.marinecare.nl



MARINE CARE

AM SCALE REMOVER LIQUID

DIRECTIONS FOR USE

AM Scale Remover Liquid is directly dosed to the vacuum line behind the toilets. Per 5-10 toilets at least one dosing unit should be present. The dosing point should be furthest from the common header. Daily dosage is 50 ml per dosing point. It is preferred the dosing of AM Scale Remover Liquid takes place during the hours the toilets are used the least (evening/nightly hours) as the AM Scale Remover Liquid has time to react with possible present scale.

Increase dosage to 100 ml per day when scale starts to form in the lines of the vacuum system.

It is strongly suggested to request Marine Care for advise for dosing points and dosing units.

PROPERTIES

Flashpoint	> 100 C
Physical state	Liquid
Specific gravity	1,1 kg/l

For detailed information on safety and health, please refer to the Material Safety Data Sheet MSDS and/or product label.

- High efficiency
- Prevents scale in vacuum systems
- Non corrosive
- 100% bio degradable



MARINE CARE BV
Oude Maasweg 35
Port number 4005
3197 KJ Rotterdam Botlek
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. supply@marinecare.nl
W. www.marinecare.nl